





Title	Project Unit
Step 1 (select Set Default option in Tools menu)	Step 2 (select project unit)
	

You can define a project unit, however, you can use any units listed in the unit list when you input a geometry.

Step 3 (start a new project)															
	 <table border="1" data-bbox="954 1577 1352 1896"> <thead> <tr> <th>Property</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>Name</td> <td>CreateCuboid</td> </tr> <tr> <td>Relative CS</td> <td>Global CS</td> </tr> <tr> <td>Position</td> <td>0mm , 0mm , 0mm</td> </tr> <tr> <td>Width</td> <td>0.6mm</td> </tr> <tr> <td>Depth</td> <td>0.8mm</td> </tr> <tr> <td>Height</td> <td>0.8mm</td> </tr> </tbody> </table>	Property	Value	Name	CreateCuboid	Relative CS	Global CS	Position	0mm , 0mm , 0mm	Width	0.6mm	Depth	0.8mm	Height	0.8mm
Property	Value														
Name	CreateCuboid														
Relative CS	Global CS														
Position	0mm , 0mm , 0mm														
Width	0.6mm														
Depth	0.8mm														
Height	0.8mm														

The default project unit will be mm. You cannot change it any more.